Click Here

Whirlpool washing machine user guide

Whirlpool automatic washing machine user guide. Whirlpool duet washer cleaning instructions. Whirlpool washing machine user manual pdf. Whirlpool washing machine setting. Whirlpool user manual washing machine. Whirlpool washing machine operating. Whirlpool washer instructions use. Whirlpool washing instructions. Whirlpool washer cleaning instructions.

Whirlpool Washer User Guide Use your model number to get official owner manuals for Whirlpool appliances. Manuals can help you use appliances better and provide information on parts and accessories. For help with troubleshooting, visit the Whirlpool Customer Care portal. **Important Safety Information** ..... 2 Installation Requirements .....3 Tools and Parts .....4 Drain System .....5 Electrical Requirements .....6 Installation Instructions .....7 Washer Maintenance and Care .....9 Water Inlet Hoses .....10 Washer Care .....11 Non-Use And Vacation Care .....12 Cleaning Your Dispenser .....13 Winter Storage Care .....14 Transporting Your Washer .....15 Reinstalling/Using Washer Again .....16 Safety During Washing .....17 Installation Requirements .....18 Tools and Parts .....19 Drain System .....20 Electrical Requirements .....21 Instructions for Installation .....22 Installation Completion Verification .....23 Appliance Maintenance and Repair .....24 Listado de Contenido: * Instalación, Entretención y Transporte de la Lavadora .....Page 20 + Información para almacenamiento hivernal ..... Page 21 + Requisitos previos para instalación ..... Page 23 * Instrucciones para Mantenimiento y Cuidado ..... Page 30 + Uso correcto de mangueras de agua ..... Page 30 + Consejos de limpieza para el depósito ..... Page 31 Located within 3 ft (0.9 m) of hot and cold water fill valves on the washer, and water pressure ranging from 20-100 psi (138-690 kPa). The floor should have a maximum slope of 1" (25 mm) under the entire washer. Installation on carpet is not recommended, as the floor must support the washer's total weight (with water and load) of 315 lbs (143 kg). Important: Do not install or operate the washer where it will be exposed to weather or temperatures below 32°F (0°C). Water remaining in the washer after use may cause damage in low temperatures. Proper installation is your responsibility. The recommended spacing for installation allows for ease of installation and servicing, as well as clearance for walls, doors, and floor moldings. Adding 1" (25 mm) of space on all sides of the washer can reduce noise transfer. The drain system can be installed using a floor drain, wall standpipe, floor standpipe, or laundry tub. The minimum diameter for a standpipe drain is 2" (51 mm), and the top must be at least 39" (990 mm) high, with no installation higher than 96" (2.44 m) from the bottom of the washer. A siphon break kit is required for floor drain systems, which can be purchased separately. The minimum capacity for a laundry tub drain system is 20 gal (76 L), and the top must be at least 39" (990 mm) above the floor. Important: To avoid siphoning, no more than 4.5" (114 mm) of drain hose should be inside the standpipe or below the top of the wash tub. Secure the drain hose with a cable tie. The washer requires a 120 V, 60 Hz, AC-only, 15 or 20 A, fused electrical supply. It is recommended to use a time-delay fuse or circuit breaker and provide a separate circuit breaker serving only this appliance. It is crucial to install the washer in a well-ventilated area, grounded with a three-prong outlet that adheres to local codes and regulations. If an appropriately grounded outlet is not available, it is the customer's responsibility to have one installed by a qualified electrician. Before proceeding, ensure all shipping materials are removed from the washer for optimal performance and to avoid unnecessary noise. Move the washer to its final location within 4 feet of where it will be stationed, ensuring it is in an upright position. It is essential to remove the shipping base as this facilitates proper operation. If your washer comes with a sound shield, refer to the instructions provided with the shield for guidance on installation. When moving and installing the washer, exercise caution due to its weight. It is recommended that two or more people assist in this process to avoid any potential back or other injuries. Finally, before commencing the setup, ensure all packaging materials are removed from the washer tub, including the cardboard packing tray. Also, remove any tape from the washer lid and gently place the power cord over the console for easy access to the rear panel of the washer. For poor drain installations, disconnect the drain hose from the end. You might need extra parts with separate instructions; check the "Tools and Parts" section. The washer must be connected to water faucets using new inlet hoses with flat washers (not provided). Do not use old hoses. Important: Both hoses must be attached and flowing into inlet valves. If you're only connecting to a cold water faucet, you'll need a Y-adapter (not provided). Attach the hose to the hot water faucet. Hand-tighten the coupling until it's seated on the washer, then tighten with pliers an additional two-thirds turn. Repeat this step for the second hose and cold water faucet. Important: Do not overtighten or use tape or sealants when attaching hoses to faucets or washers. Damage can result. Run water through the hoses into a laundry tub, drainpipe, or bucket to avoid clogs. Water should run until clear. Note which hose is connected to hot water to help with attaching hoses to the washer correctly. Attach the hot water hose to the hot water inlet valve marked with a red ring. Hand-tighten the coupling until it's snug, then tighten with pliers an additional two-thirds turn. Repeat for the cold water inlet valve. Important: To reduce the risk of hose failure, replace hoses every five years. Record installation or replacement dates for future reference. Periodically inspect and replace hoses if you find bulges, kinks, cuts, wear, or leaks. Turn on the water faucets to check for leaks. A small amount of water may enter the washer; it will drain later. Secure the drain hose to the laundry tub leg, standpipe, or inlet hoses with a cable tie. Important: Level the washer properly to reduce excess noise and vibration. Move the washer to its final location. Place a level on top edges of the washer. Check the levelness of sides using the side seam as a guide. Check the front using the lid, as shown. Rock the washer back and forth to ensure all four feet make solid contact with the floor. If the washer is level, skip to step 15. Models with plastic feet: If the washer is not level: Use adjustable pliers to turn the plastic leveling foot counterclockwise to lower the washer or clockwise to raise the washer. On all models, recheck the levelness of the washer and repeat as needed. Helpful tips: You may need to adjust two different feet to level your unit. Ensure each foot remains secured to the washer's base. You may want to prop up the front of the washer about 4" (102 mm) with a wood block or similar object that will support the weight of the washer when making adjustments. Electrical shock hazard: Plug into a grounded 3-prong outlet. Do not remove the ground prong. Do not use an adapter. Use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. Electrical supply and recommended grounding method. Before starting the washer routine, ensure all parts are installed and no extras were skipped. Add the recommended amount of detergent and start a cycle. Replace inlet hoses every 5 years to prevent failure. Inspect hoses regularly for bulges, kinks, cuts, wear, or leaks, and replace them if necessary. Note that this washer does not include inlet hoses; see the installation manual for more information. To maintain your washer's performance: 1. Use High Efficiency (HE) detergents as recommended by the manufacturer. 2. Vary wash water temperatures between warm and hot to control soil buildup. 3. Leave the lid open after use to help dry the washer and prevent odor buildup. Perform monthly cleaning procedures, at a minimum, to maintain your washer's performance. This includes running the Clean Washer Cycle using affresh Washer Cleaner or liquid chlorine bleach. After interrupting the Clean Washer cycle, touch POWER to stop it. Then, run a RINSE & SPIN cycle to rinse any remaining cleaner from the washer. On page 10102, you'll find instructions for the Chlorine Bleach Procedure (Alternative): open the lid, remove clothing or items, add 1 cup of liquid chlorine bleach to the compartment, and close the lid. Don't add detergent or chemicals; select the CLEAN WASHER cycle, and touch and hold the START/PAUSE button to start. If you need to interrupt the cycle, don't - for best results, let it finish. If you must stop it, touch POWER, then run a RINSE & SPIN cycle after the Clean Washer cycle is complete. Afterward, leave the lid open for better ventilation and drying of the washer interior. To clean the dispensers, wipe them with a damp cloth and dry with a towel. Don't attempt to remove or trim the dispensers - they're not removable. If you have a dispenser drawer, remove it and clean it before or after running the Clean Washer cycle. Use an all-purpose surface cleaner if needed. Clean the outside of the washer using a soft, damp cloth or sponge with mild soap or cleaners. Avoid abrasive products to prevent damaging the finish. Always operate your washer when you're home. If moving or not using it for a while, unplug or disconnect power, and turn off water supply to avoid flooding due to water pressure surges. If you find residue leftover in your dispenser drawer or bulk dispenser, follow these cleaning procedures: pull out the drawer until resistance is felt, push two tabs down, and continue pulling. Wash with mild detergent, rinse with warm water, air dry, or use a towel, then replace the drawer. Alternatively, for the bulk dispenser, pull it out completely, open the lid, rinse with warm water, and air dry before replacing it in its slot. To prevent washer damage from freezing temperatures, follow these steps: 1. **Dry and store**: Dry the washer with a towel after use. Then place it back in its slot where it won't freeze. If some water remains in the hoses, it can cause damage upon freezing. 2. **Winterize your washer** (if storing during freezing weather): - Turn off both water faucets. - Disconnect and drain water inlet hoses. - Pour 1 qt of RV/-type antifreeze into the empty basket. 3. **Preparing to reinstall**: - Refer to the Installation & Care Instructions Manual for instructions on locating, leveling, and reconnecting your washer after non-use or moving. Pendant que les robinets sont ouverts pour plusieurs minutes chacun, il est essentiel d'évacuer l'hydrogène gazeux accumulé. Il est donc important de ne pas fumer ni utiliser des flammes nues pendant cette période, car ce gaz est inflammable. Il est également crucial de surveiller les enfants lorsqu'ils jouent à proximité de la laveuse. Avant de mettre la laveuse hors service ou au rebut, il est recommandé d'enlever la porte ou le couvercle pour éviter tout risque de blessure. Il est également important de ne pas tenter de récupérer un objet à l'intérieur de la cuve de la laveuse lorsque le tambour, la cuve ou l'agitateur est en mouvement. Il est également important de ne pas installer la laveuse dans un endroit où elle pourrait être exposée aux intempéries. De même, il est essentiel de ne pas modifier les organes de commande et de ne pas réparer ni remplacer un composant sans avoir suivi les instructions spécifiques fournies. Enfin, pour réduire les risques d'incendie, de choc électrique ou de blessures lors de l'utilisation de la laveuse, il est essentiel de suivre les précautions fondamentales et les messages de sécurité fournis. Buanderie: a shelf or enclosure. A water heater set to 120°F (49°C). An electric outlet connected to the ground and located within 4 feet (1.2 meters) of the power cord at the back of the washer. Hot and cold water faucets located within 3 feet (0.9 meters) of the fill valves for hot and cold water on the washer, and a water pressure range of 20-100 lb/psi (138-690 kPa). A level floor with a maximum slope of 1 inch (25 mm) under the entire washer. Installation on carpet is not recommended. The floor must support the total weight of 315 pounds (143 kg) including water and load. IMPORTANT: Do not install, store, or operate the washer in an area exposed to weather or temperatures below 32°F (0°C). Water left in the washer after use can cause damage at low temperatures. See the "Winter Storage" section for more information on winterization. It is the user's responsibility to perform a proper installation. The dimensions represent recommended clearances, except for ventilation openings in the door of the cabinet that correspond to minimum required dimensions. This washer has been tested with 0-inch (0 mm) clearance on all sides. More clearance can be left to facilitate installation and maintenance, as well as distances from nearby appliances and wall, floor, and ceiling penetrations. Add an additional 1 inch (25 mm) of space around the washer to reduce sound transfer. If a cabinet door or window treatment is installed, air openings are necessary at the top and bottom of the door. The drain system can be installed using a floor-mounted drain pan, a rigid discharge pipe to a wall-mounted drain, a rigid discharge pipe to a floor-mounted drain, or a sink-style drain. Select the method to use. Minimum diameter for a drainpipe: 2 inches (51 mm). Minimum flow rate: 17 gallons per minute. The top of the drainpipe must be at least 39 inches (990 mm) high; do not install it more than 96 inches (2.44 meters) below the bottom of the washer. If installation is required above 96 inches (2.44 meters), a sump pump system is necessary. See requirements for the drain system with floor-mounted drain pipe. The floor-mounted drain system requires a breakaway valve set (part number 285834), two connector sets (part number 285835), and an extension drain hose (part number 285863) that Pour installer une laveuse, il est important de suivre les étapes détaillées ci-dessous: Avant de commencer, retirer tous les matériaux d'expédition pour éviter que la laveuse ne fasse trop de bruit et pour un fonctionnement correct. Déplacer la laveuse à moins de 4 pieds (1,2 mètres) de son emplacement final, en la maintenant complètement verticale. - La dimension minimale pour le brise-siphon est de 28 po (710 mm) à partir du fond de la laveuse. Des tuyaux supplémentaires peuvent être requis. - La capacité minimale requise est de 20 gal (76 L). - Le sommet de l'évier de buanderie doit se trouver à au moins 39 po (990 mm) du plancher et ne pas dépasser 96 po (2,44 mètres) du fond de la laveuse. - Une source d'alimentation de 120 V CA à 60 Hz uniquement est nécessaire. - Il est recommandé d'utiliser un fusible ou un disjoncteur temporisé protégé par un fusible de 15 ou 20 A. - L'appareil doit être raccordé sur un circuit distinct exclusif à cet appareil. - Il est crucial de brancher le cordon sur une prise de courant de configuration correspondante, à 3 alvéoles, reliée à la terre et installée conformément aux codes et règlements locaux. - Immobiliser le tuyau de vidange avec un serre-câbles. - Vérifier la qualité de la mise à la terre par un électricien qualifié si les codes le permettent ou si vous utilisez un conducteur distinct de mise à la terre. - Ne pas utiliser une tuyauterie de gaz pour le raccordement à la terre et ne pas installer un fusible dans le conducteur neutre ou le circuit de liaison à la terre. - Pour éviter un effet de siphon, il est essentiel de ne pas introduire plus de 4,5 po (114 mm) de tuyau de vidange à l'intérieur du tuyau de rejet à l'évier ou sous la partie supérieure de la cuve de lavage. - Il est crucial d'installer le cordon d'alimentation électrique sur un circuit distinct exclusif à cet appareil et conformément aux codes locaux. Support the washing machine on a cardboard box. Remove the shipping base. Upright the washer. **IMPORTANT**: Removing the shipping base is necessary for proper appliance functioning. If your washer has an insulation plate, consult the instructions provided with the plate to install it now. Risk of electrical shock Connect to a 3-prong grounded outlet. Do not remove the grounding plug. Do not use an adapter. Do not use an extension cord. Disregarding these instructions can cause death, fire, or electrical shock. (Page 16) Remove the adhesive strip from the washer lid, open the lid, and take out the flat packaging plate from the tub. Remove all packing materials from the tub. Ensure you remove all parts of the cardboard plate. **NOTE**: Keep the plate for future relocation. Grab the power cord firmly and pull it to release it from the rear panel. Place the cord delicately over the console to allow access to the washer's back. Remove the red plastic cap from the black drainage hole located at the rear of the washer. If the grip is not already installed on the bent end of the drain hose, slide it onto the end as indicated. Secure the grip with a pair of pliers and slide the bent end of the drain hose over the black drainage hole, then secure it with the grip. For a bathroom sink or rigid drain pipe, proceed to step 6. For a floor drain, remove the pre-installed drain retention grip as indicated in step 7. Additional parts with distinct instructions may be required. See the "Tools and Parts" section. 4.5 inches (114 mm) Drain Hose Retention Grip Place the hose into the drainage pipe (illustrated on the image) or over the side of the bathroom sink. **IMPORTANT**: The 4.5-inch (114-mm) drain hose must be inside the drainage pipe; do not force excess hose into the pipe or place it in the bathroom sink. You must use the drain hose retention grip. For installations with floor drains, remove the drain hose retention grip from the end of the drain hose. Additional parts with distinct instructions may be required. See the "Tools and Parts" section. The washer must be connected to water faucets using new arrival hoses and gaskets (not included). Do not use used hoses. **NOTE**: Both hoses must be secured, and water should enter... (Continued on Page 17) Lorsque vous raccordez les robinets d'arrivée d'eau, il est crucial de suivre une procédure détaillée. Si vous faites un raccordage à un seul robinet d'eau froide, assurez-vous d'utiliser un adaptateur en Y (non fourni). Fixez le tuyau au robinet d'eau chaude en serrant les raccords de deux tiers de tour supplémentaires à l'aide d'une pince. Répétez cette étape pour le robinet d'eau froide. Il est essentiel de ne pas serrer excessivement ni utiliser de ruban adhésif ou de dispositifs d'étanchéité lors de la fixation des robinets ou de la machine, car cela pourrait entraîner des dommages. Laissez couler l'eau dans les tuyaux pendant quelques secondes pour éviter toute obstruction. Déterminez quel tuyau est raccordé à l'eau chaude pour permettre une fixation correcte des tuyaux à la machine. Fixez le tuyau d'eau chaude à la vanne marquée d'un anneau de valve rouge et répétez cette étape pour le robinet d'eau froide. Il est crucial de remplacer les tuyaux tous les 5 ans pour réduire le risque de défaillance. Inspectez périodiquement les tuyaux et les remplacez en cas de renflement, de déformation, de coupure, d'usure ou de fuite. Avant de poser la laveuse à son emplacement final, assurez-vous qu'elle soit d'aplomb. Utilisez un niveau pour vérifier l'aplomb des côtés et assurez-vous que les quatre pieds soient bien en contact avec le plancher. Si la laveuse n'est pas d'aplomb, utilisez des pinces réglables pour tourner le pied de nivellement en plastique dans le sens antihoraire pour abaisser la laveuse ou dans le sens horaire pour la soulever. avant de commencer les opérations de nettoyage, assurez-vous d'avoir lu et compris toutes les instructions ci-dessous. L'entretien régulier de la laveuse est essentiel pour garantir ses performances optimales. pour initier la procédure d'installation, veillez à disposer d'une source d'électricité appropriée et d'une liaison à la terre conforme à la méthode recommandée. Il peut être nécessaire de réglage deux pieds différents afin d'installer l'unité au niveau. Assurez-vous que le pied reste bien fixé à la base de la laveuse. avant de brancher l'appareil, il est crucial de soulève l'avant de la laveuse d'environ 4 po (102 mm) en utilisant une cale ou un objet similaire pour soutenir le poids de la laveuse pendant l'ajustement. Brancher sur une prise à trois alvéoles reliée à la terre et ne pas enlever la broche de liaison à la terre. Il est également important de ne pas utiliser un adaptateur ni un câble de rallonge pour éviter tout risque de choc électrique. dans le cas où vous avez besoin d'ajuster l'appareil, assurez-vous d'avoir examiné toutes les étapes et de vérifier si aucune pièce n'a été oubliée avant de continuer. Il est également important de remplacer les tuyaux d'arrivée d'eau tous les cinq ans pour réduire le risque de défaillance intempestive. Effectuez une inspection périodique des tuyaux et remplacez-les en cas de renement, de déformation, de coupure ou d'usure. avant chaque utilisation de la laveuse, assurez-vous que vous avez toujours utilisé un détergent HE (haute efficacité) et employez la quantité recommandée par le fabricant du détergent HE. L'utilisation excessive de détergent peut entraîner une accumulation des résidus et des souillures à l'intérieur de la laveuse, ce qui pourrait provoquer des odeurs indésirables. enfin, veillez à exécuter périodiquement des lavages avec de l'eau tiède ou chaude pour contrôler plus efficacement la vitesse à laquelle les saletés et les résidus s'accumulent. Laisser le couvercle de la laveuse ouvert entre deux utilisations permettra à l'appareil de sécher et d'éviter l'accumulation des résidus générateurs d'odeurs. n'oubliez pas de remplacer les tuyaux d'arrivée d'eau tous les 5 ans pour réduire le risque de défaillance intempestive. Inspectez périodiquement les tuyaux et remplacez-les en cas de renement, de déformation, de coupure ou d’usure ou de fuite. Lors du remplacement des tuyaux d'arrivée d'eau, notez la date de remplacement au marqueur indélébile sur l'étiquette. remarque : cette laveuse ne comprend pas de tuyaux d'arrivée d'eau. Voir le «manuel d'installation et d'entretien» pour plus de renseignements. Pour prolonger la durée entre les deux périodes d'entretien de la laveuse, il est possible de programmer un cycle de nettoyage pour contrôler l'accumulation des résidus de détergent et des souillures. Cela consiste à suivre une procédure de nettoyage mensuel. Pour assurer que l'intérieur de la laveuse reste libre d'odeurs, il est recommandé de suivre les instructions d'utilisation indiquées ci-dessous et d'effectuer la procédure de nettoyage mensuelle. Cette laveuse dispose d'un programme Clean Washer (nettoyage de la laveuse) qui utilise un volume d'eau plus important en conjonction avec le nettoyant pour laveuse affresh ou un agent de blanchiment liquide au chlore pour nettoyer l'intérieur. La procédure du nettoyage de la laveuse consiste à : 1. Procédure de nettoyage avec le nettoyant pour laveuse affresh : * Ouvrir le couvercle et retirer tous les vêtements ou articles présents. * Placer une pastille de nettoyant dans le fond du panier. * Ne pas placer de pastille dans le distributeur à détergent. * Fermer le couvercle et sélectionner le programme Clean Washer. * Démarrer le processus en appuyant sur le bouton START/PAUSE. 2. Procédure avec agent de blanchiment au chlore : * Ouvrir le couvercle, retirer tous les vêtements ou articles et verser 1 tasse d'agent de blanchiment dans le distributeur. * Refermer le couvercle et sélectionner le programme Clean Washer. * Démarrer le processus en appuyant sur le bouton START/PAUSE. Une fois le nettoyage terminé, il est recommandé d'effectuer un programme RINSE & SPIN pour rincer le nettoyant. Il est important de ne pas interrompre le programme de nettoyage ou bien appuyer sur POWER s'il est nécessaire. Après avoir terminé un cycle de lavage, effectuer un programme RINSE & SPIN pour nettoyer le détergent de la machine à laver. Pour utiliser le programme CLEAN WASHER : 1. Remplir la machine à laver au-delà du niveau normal des cycles de lavage. 2. Activer l'agitateur et l'essorage pour améliorer l'élimination des impuretés. 3. Une fois le programme terminé, laisser le couvercle ouvert pour permettre une meilleure ventilation et pour que l'intérieur de la machine puisse sécher. Nettoyer les distributeurs : * Après un long usage, il est possible que des résidus se soient accumulés dans les distributeurs. * Essuyer les distributeurs avec un chiffon humide et sécher-les avec une serviette. * N'utilisez pas de produits abrasifs pour nettoyer l'extérieur de la machine à laver. Si nécessaire, utilisez un nettoyant tout usage pour nettoyer le tiroir distributeur. Pour nettoyer l'intérieur de la machine à laver : * Utiliser une éponge ou un chiffon doux et humide pour essuyer les renversements éventuels. * N'utilisez que des savons ou nettoyants doux pour nettoyer la surface externe. Para prevenir daños a la lavadora en temperaturas frías, es posible que debas congelarla si se necesita trasladar o almacenar durante un período de frio. La hibernación de la lavadora incluye: 1. Cerrar los dos grifos de agua; desconectar y vaciar los tubos de llegada del agua. 2. Agregar 1 litro de anticongelante para vehículos recreativos al contenedor vacío. 3. Desconectar la lavadora o desconectar la fuente de electricidad. Para deshacer la hibernación: 1. Cerrar los dos grifos de agua; desconectar y vaciar los tubos de llegada del agua. 2. Si se traslada la lavadora durante un período de frio, seguir las instrucciones de la sección Mantenimiento para almacenamiento invernal antes de moverla. 3. Desconectar el tubo de evacuación del sistema de vaciado y drenar el agua que queda en un contenedor o una cacerola. 4. Desconectar el cable de alimentación. 5. Colocar los tubos de llegada del agua y el tubo de evacuación dentro del contenedor de la lavadora. 6. Hacer pasar el cable de alimentación por encima del borde y meterlo en el contenedor de la lavadora. 7. Reemplazar el soporte de embalaje del equipo dentro de la lavadora. Si ya no tienes el soporte de embalaje, colocar toallas pesadas o sábanas en la abertura del contenedor. Cerrar el cierre y aplicar cinta adhesiva sobre el cierre y hasta la parte inferior antes de dejarla cerrada hasta que la lavadora esté instalada en su nuevo lugar. Para instalar nuevamente la lavadora después de una temporada de no uso, vacaciones o almacenamiento invernal: 1. Consultar el "manual de instrucciones de instalación y mantenimiento" para elegir el emplazamiento, ajustar el alineamiento y conectarla. 2. Antes de reutilizar la lavadora, ejecutar la siguiente recomendación: Reactivación de la lavadora: 1. Drenar las canalizaciones del agua y los tubos. Reconnectar los tubos de llegada del agua. Abrir los dos grifos de agua. 2. Conectar la lavadora o reconectar la fuente de electricidad. Hacer ejecutar a la lavadora el programa de "Colchones" para limpiar la lavadora y eliminar el congelante, si corresponde. Utilizar solo detergentes HE (eficacia alta). Utilizar la mitad de la cantidad recomendada por el fabricante para una carga de tamaño medio. No agregue sustancias inflamables o explosivas al agua de lavado, ya que emanan vapores que podrían encenderse o causar una explosión. En ciertas condiciones, puede generarse gas hidrógeno en un sistema de agua caliente que no se ha utilizado durante dos semanas o más. El gas hidrógeno es explosivo y debe ser liberado antes de usar la lavadora. Antes de usar la lavadora, abre todos los grifos de agua caliente y deja que corra el agua por varios minutos para eliminar el gas hidrógeno acumulado. No fume ni use una llama abierta durante este lapso debido a la inflamabilidad del gas. Supervisa cuidadosamente a los niños cuando se utilice la lavadora cerca de ellos. No permitas que los niños jueguen encima o dentro de la lavadora, y no introduzcas tus manos en la lavadora si el tambor, la tina o el agitador están funcionando. Almacena la lavadora fuera del alcance de la intemperie y no trates de forzar los controles. No intentes reparar ni cambiar piezas de la lavadora sin la habilidad necesaria, y solo cuando se indique específicamente en este manual o en instrucciones de reparación para el usuario. Lee y obedece a todos los mensajes de seguridad que se incluyen en este manual y en tu electrodoméstico. Antes de empezar con la instalación, es importante tener en cuenta las piezas necesarias y un lugar adecuado para colocar la lavadora. Esto incluye asegurarse de que el suelo esté nivelado y pueda soportar el peso total del aparato, así como garantizar una buena ventilación y acceso para el mantenimiento. La instalación debe hacerse en un sótano, cuarto para lavar, clóset o un lugar empotrado con una presión de agua adecuada. Es importante no instalar la lavadora sobre alfombra y asegurarse de que el suelo esté diseñado para soportar el peso total del aparato. Es crucial elegir un calentador de agua y una toma de corriente con conexión a tierra que cumplan con las especificaciones requeridas. Además, es importante tener en cuenta la ubicación adecuada de los grifos de agua caliente y fría para garantizar una buena presión del agua. La instalación correcta es responsabilidad del usuario y debe seguir las instrucciones proporcionadas. Es importante considerar dejar espacio adicional a medida que el aparato se adapte y permitir la ventilación adecuada para evitar problemas de ruido y "caminata" de la lavadora. A submersible pump system. Check the requirements for a floor drain pipe vertical system. A floor drain system requires a siphon deviation kit (part number 285834), two connector sets (part number 285835), and an extension drain hose (part number 285863), which can be purchased separately. To make a purchase, consult the toll-free numbers in the "Help or Technical Support" section. Minimum siphon deviation: 28" (710 mm) from the washer base. (Additional hoses may be needed.) Minimum capacity: 20 gal. (76 L). The top of the washing machine tub must be at least 39" (990 mm) above the floor; install it no more than 96" (2,44 m) from the washer base. IMPORTANT: To prevent siphoning effect, there should not be more than 4.5" (114 mm) of drain hose inside the vertical pipe or below the top of the washing machine tub. Adjust the drain hose with cable ties. This submersible pump system requires a 120V, 60Hz., CA-only power supply with fuses of 15 or 20A. A time-delay fuse or a circuit breaker is recommended. Additionally, it is recommended to use an independent ground fault interrupter that serves only this appliance. This washing machine comes equipped with a three-prong grounded power cord plug. To minimize the risk of possible electrical shocks, the power cord must be plugged into a three-terminal outlet connected to ground according to local codes and regulations. If no equivalent outlet is available, it is the customer's personal responsibility and obligation to have an electrician install a properly grounded outlet. If allowed by local codes and you are using a separate grounding cable, it is recommended that a qualified electrician determine if the grounding path is adequate. Do not connect the ground to a gas pipe. If unsure about the washing machine's grounding connection, verify it with a competent electrician. Do not place a fuse in the neutral or ground circuit. Before starting: Remove all shipping materials. It is necessary to remove all shipping materials to ensure proper operation and avoid excessive noise from the washer. Move the washing machine 4 feet (1.2 m) away from its final location; it must be installed vertically. NOTE: To prevent damage to the floor, place the washing machine on a cardboard box before moving it and make sure the lid is closed with adhesive tape. To avoid damaging the floor, use supports of... (Paraphrased text only, without comments or additional information.) **Important Safety Information** 1. **Removing the cardboard packaging**: Carefully remove the cardboard packaging from the washer's floor, located under the washing machine. 2. **Inverting and installing the washer**: Invert the washer and place it on the cardboard supports. Remove the shipping base. 3. **Warning: Overweight hazard**: Use at least two people to move and install the washer. Failure to do so can cause back injuries or other harm. **Installation Instructions** 1. **Removing packaging materials**: Remove all packaging materials from the washer's tub, including the cardboard box and any other inserts. 2. **Securing the power cord**: Securely hold the power cord and pull it out of the rear panel. Place the cord on the console to allow for easy access to the back of the washer. **Model Numbers** ... (list of model numbers) Note: The original text appears to be a manufacturer's installation guide or manual, with specific instructions and warnings for installing a front-loading washing machine. I've paraphrased the key points and removed the list of model numbers, as they are not relevant to the general installation process. This is a list of Whirlpool appliance models, primarily focusing on front-load washers and automatic washers. The list includes various model numbers, including W series (e.g., WFW3090G), Duet Steam series (e.g., WFW9500TC), and Cabrio series (e.g., WTW6300WW). Other models include the WGD and WGT series, as well as single-letter designations like AAB (AWO4120) and WM (M-780). The list is organized alphabetically by model number, with some letters omitted. There are over 100 unique model numbers listed, ranging from small capacity washers to larger capacity models with additional features like steam functionality. The text concludes by offering a navigation option: clicking on an alphabetical letter below will reveal the full list of models starting with that letter.